

How to know the Serial Number of a DECS-200 AVR

There are 2 ways to identify the Serial number of a DECS-200:

- 1- Locate the sticker on the side of the unit
- 2- When opening the box, the serial number is indicated on the test report

Please find below the procedure using both methods

METHOD 1:

Locate the sticker on the left side of the DECS-200 Unit



The Serial number is identified by a series of letters and numbers, starting with "S/N"



The Serial number starts with the letter H. In this example, the serial number is H01458784

You will also notice that the type of DECS-200, the style number is indicated just below. In this example, it is a DECS-200-1C (This defines the type of control power supply & the ability to have external tracking with another unit)

You will also notice just below a second sticker, with a 10 digit number starting by 9. This is the part number and can be used to order an identical unit.

